

Preventative Maintenance Program



tecresq@cox.net

702-292-5306

You've invested in the highest performing rescue equipment, make sure it is professionally maintained annually so that it can perform its life saving functions when you need it. Avoid downtime and unnecessary repair expense with our comprehensive annual preventative maintenance. We are systematic, thorough, and care about keeping your tools in great working condition.

Holmatro Pump Services

Hydraulic Unit:

- Check Power Unit for external damage & oil leaks
- Check Frame/carrying handle for damage
- Check for correct hydraulic oil volume output
- Check Pump switchover valve pressure setting, correct if necessary
- Check Pump pressure output, correct if necessary
- Inspect and clean intake screens on hydraulic system
- Inspect/check plunger blocks
- Clean hydraulic tank interior of all models except PPU & TPU pumps
- Check Selector Valve for proper operation
- Check Couplers for dirt and damage; clean by removing any dirt with WD-40
- Check Dust Caps to ensure that they are present, clean, & working properly
- Change Hydraulic oil and fill with Holmatro Hydraulic Mineral Oil
- Replace normal wear items at no additional charge

Engine Gasoline

- Check for external damage.
- Check for quick starting, and correct operation under full load
- Check for correct motor RPM's, correct if necessary
- Change the crank case motor oil

- Replace Fuel Filter, if equipped
- Check Starting Cord for damage
- Check Muffler for damage & correct attachment
- Check Spark Arrestor and clean or replace if equipped
- Treat fuel tank with Sea Foam fuel stabilizer
- Replace normal wear items at no additional charge

Electric Motor

- Check the Switch for proper operation
- Check Cable & Plug for damage & proper attachment
- Check Motor under full load
- Replace normal wear items at no additional charge

Holmatro Spreader Services

- Check the Tool for external damage &/or oil leakage
- Check Arms for visible distortions, or damage
- Remove Tips check for distortions, damage, & clean
- Check Tip Release Pins for damage & clean
- Check all Hinge Pins for damage, replace any distorted or rusted "C" Clips/Snap rings
- Check Grease points-Clean all control and handle parts, arms, hinge pins & levers
- Inspect main valve
- Replace all o-rings in handle assembly
- Re-Grease all control and handle parts with White Lithium grease
- Re-Grease metal to metal moving parts with Synthetic Grease
- Replace Hydraulic Oil in tool with new Holmatro approved Hydraulic Mineral Oil
- Check Carrying Handle for damage
- Check Yoke and Plunger for any damage

Preventative Maintenance Program

- Torque all bolts and nuts according to Holmatro Specs
- Check Couplers for dirt and damage; clean by removing any dirt with WD-40
- Check for proper operation of safety relief valve
- Check Pulling Tips & Chains for damage, if present
- Check Pigtail Hoses for hydraulic leaks or damage, if equipped
- Replace normal wear items at no additional charge

Holmatro Hose Services

- Check the Hose for external damage and/or oil leakage
- Pressure Test Hose at Maximum Operating Pressure
- Check crimped ends at couplings for leakage
- Replace Hydraulic Oil in tool with new Holmatro approved Hydraulic Mineral Oil
- Check Couplers for dirt and damage; clean by removing any dirt with WD-40
- Replace normal wear items at no additional charge

Holmatro Cutter / Combi-tool Services

- Check the Tool for external damage and/or oil leakage
- Check Blades for visible cracks, blunt edges, or distortions
- Dress Blade edges
- Check all Hinge Pins for damage; replace any distorted or rusted "C" Clips/Snap rings
- Check Grease points, clean all handle parts, hinge pins, blades, & levers
- Inspect main valve
- Replace all o-rings in handle assembly
- Re-Grease all control and handle parts with White Lithium grease
- Re-Grease metal to metal moving parts with Synthetic Grease
- Replace Hydraulic Oil in tool with new Holmatro approved Hydraulic Mineral Oil
- Check Carrying Handle for damage
- Check Yoke and Plunger for any damage
- Torque all bolts & nuts according to Holmatro Specs
- Check Couplers for dirt or damage; clean by removing any dirt with WD-40
- Check for proper operation of safety relief valve
- Check Pigtail Hoses for hydraulic leaks or damage, if equipped
- Replace normal wear items at no additional charge

Holmatro Ram Services

- Check the Tool for external damage and/or oil leakage

- age
- If Ram has Carrying Handle check for damage
- Check Grease points-Clean all control & handle parts
- Inspect main valve
- Replace all o-rings in handle assembly
- Replace Hydraulic Oil in tool with new Holmatro approved Hydraulic Mineral Oil
- Re-Grease all control and handle parts with White Lithium Grease
- Check Cross Heads for damage remove clean and Re-Grease with Synthetic Grease
- Check Plunger-Extend fully open and look for any damage
- Check Couplers for dirt or damage, clean by removing any dirt with WD-40
- Check Pigtail Hoses for hydraulic leaks or damage, if equipped
- Check all Accessories & Ram Extensions for damage, if present
- Replace normal wear items at no additional charge

Service Charges 2010

SVC17, Labor	\$75.00
SVC33, Travel Time	\$75.00
SVCHHOSE, Holmatro Hose PM	\$25.00
SVCHP01, Pump, 4000/2040 PM	\$145.00
SVCHP02, Pump, 2035/PPU20/PU5/DPU30 PM	\$125.00
SVCHP03, Pump, PPU15/DPU31 PM	\$175.00
SVCHP04, Pump, 2060/DPU60/MPU60 PM	\$200.00
SVCHP05, Pump, Manual, PM	\$50.00
SVCHREEL, Hose Reel PM	\$50.00
SVCHT01, Tool, Cutter/Spreader/Combi PM	\$125.00
SVCHT02, Ram PM	\$75.00
SVCHT03, Mini Tool, 3005/HMC8U/SMC4000	\$50.00